

TRACY BOARDING LADDER

BL-STOW

STOWAGE KIT

INSTALLATION INSTRUCTIONS

**NOTE: PLEASE READ AND UNDERSTAND
THESE INSTRUCTIONS COMPLETELY
BEFORE ATTEMPTING THE INSTALLATION**

DECK MOUNT BRACKETS



UPPER MOUNT. BRACKET



STOWAGE KIT PARTS

INSTRUCTIONS

1. Drill two 9/32” diameter holes in the Boarding Ladder Side Rails as shown in Diagram #1
2. Insert the pins on the Deck Mount Brackets into the holes drilled in the side rails as described in Step #1.
3. Position the Boarding Stair in the location it will be stored in. Make sure there is either a bulkhead or railing within 8 inches of the top rails so that the Upper Mounting Bracket has a surface to be secured to.
4. Mark the 4-holes (2 in each Deck Mount Bracket) for locating the mounting screws. We recommend using #12 or larger screws, or 1/4” bolts to secure the brackets.
5. After the Deck Mount Brackets are installed, re-position the Boarding Stair on the brackets, making sure that the holes drilled in the side rails match up with the brackets secured to the deck.
6. With the Boarding Stair mounted on the Deck Mount Brackets, determine where the Upper Mounting Bracket will be secured. See Diagram #2. Once the location is determined, drill a 1/4” hole in the tube as shown in Diagram #2.
7. Due to the many different possibilities as to what the Upper Mounting Bracket may be mounted to, the method of securing this bracket should be determined by the boat owner and mechanics. We would recommend either thru bolting or welding the bracket to an existing railing, if possible.

